


# Quick Setup and Installation Guide

For more detailed information, insert the Installation Disc into the PC and click the **User Guide** button on the Setup Launcher main page.


# **Unpack:**




Remove tape and packing materials


(a) Remove tapes.






(continued on next page)










### **c** Remove cardboard.






Squeeze latches to open clamshell





## 2 Connect power






Do not connect the printer to a PC until prompted to do so during the Printer Driver Installation!



#### Choose display language







If Language option is not available, see Selecting the Security Level in Chapter One of the User's Manual.




# 3 Install ink cartridges










**C** Open printhead latch fully.



d Remove caps.


Do not discard caps!





(e) Remove cover from printhead




# **f** Slowly remove tape from electrical contacts and nozzles








Check that ink is flowing through the tubes on both sides of the printhead.




# 5 Load sample media




Flat side against media roll.

## 6 Print test label

#### Requires inter-label gap or continuous media



#### Sample PQ Plot



#### Top Section:

- Lines are defined with no missing nozzles
- Lines are printed in order: Yellow, Black, Cyan, Black, Magenta
- Vertical dashed lines are straight

#### Middle Section:

- All yellow, black, cyan, black, magenta lines are printed
- No color mixing on the color bars
- Numbers 1, 3, 5 are visible

#### **Bottom Section:**

- Lines are defined with no missing nozzles
- Lines are printed in order: Yellow, Black, Cyan, Black, Magenta


#### Overall:

• No streaking or smearing


7 Install printer driver

Before installing printer driver, ensure the computer meets minimum system requirements (see System Requirements in the User Manual Appendix).


#### To connect printer to computer using USB








**d** Connect USB cable when prompted.





#### To connect printer to network

a Connect printer to network using Ethernet





If you will be using DHCP to set the IP Address, skip to step **c**.

To assign the printer a Static IP address, please see Selecting the Security Level in Chapter One of the User Manual before proceeding to step c.



(d)

 $(\mathbf{e})$ 



